

ADPT-022

Packing Check List

Item	Description	Quantity
	For ADPT-022	
1.	ADPT-022	1
2.	Velcro ® strip loop for cellphone	1

Installation Instructions

Phone Mounting

Connect the connector at the end of the Adaptor cable to the connector on the high gain antenna. Please note that the phone and network take up to 20 seconds to update the signal strength indicator on the display of the phone.

The adaptor has "Velcro ®" with adhesive backing, peel off the protective backing and place the adaptor against the back of your phone. The Velcro ® allows the phone to be removed from the coupler and repositioned for the best performance. It is not necessary to use the Velcro ®, one can simply touch the phone to the adaptor.

Wait approximately 20 seconds for the cellphone and tower to communicate with each other. Should signal be weak or still not present, reposition the adaptor up or down each time waiting to see if the signal improves. You may also rotate the coupler to see if this improves the signal. If you do not get any signal on the phone you may try to align the antenna outside better to point to the nearest cellular base station tower. Please note that even one bar of signal strength is mostly sufficient for perfect communications with an outdoor antenna.

If you get no signal under any circumstances then you are most probably in an area which is outside cellphone coverage. If you get a signal, but cannot make a call you may be more than 35km (for some base stations it may be 115km) away from the base station in which case the network rejects your signal because of the time delay – this cannot be corrected by any antenna.



PLEASE NOTE THE FOLLOWING

The adaptor is designed to be used with high gain antennas only. A minimum antenna gain of 10dBi is recommended with the shortest possible low loss cable to the adaptor. Poynting cannot guarantee the successful operation of the adaptor when used with third party antenna products.